

1. Remove the die box by sliding to the left (... see "PUSH" on die box).



2. Fill the slots in the back of the die box with MaxLight™ Ink.



3. Insert the die box by inserting from the right. Allow the ink to disperse for 30 minutes.

