


When the ink in your AutoMark XL Stamp starts to run out, you can easily re-ink the stamp for thousands more impressions.

**Re-inking the AutoMark XL Stamp:**

1. Hold the AutoMark XL base firmly in your hand and remove the top.
2. Using **MaxLight** ink ONLY, squirt drops of ink into the round cylinders (AM-75 to AM-115 - 5 drops; AM-125 to AM-275 - 10 drops; AM-700 to AM-800 - 20 drops).
3. Re-install handle
4. Let stand overnight
5. Repeat if necessary

**Notes on re-inking your AutoMark XL Stamp:**

1. Time Required: After re-inking wait 12 hours before using to allow ink to penetrate the AutoMark XL system.
2. If after this time copy is still too light, re-ink again.
3. Refill with the same color ink as your original stamp.
4. After inking, leave the AutoMark XL in an upright position to prevent leakage and to allow complete ink absorption.

